



MIDI SMART-LINK

Art. No. 3470

MIDI SMARTLINK allows you to control most devices compatible with the MIDI standard.

INSTALLATION

Plug the snap-lock connector into one of the ports on the back of a SMARTPAX. Connect the male DIN plug to the MIDI IN port of the device to be controlled.

CONFIGURATION

In most cases, SMARTPAX is configured automatically from Dataton TRAX. You must, however, manually set the SMARTPAX port address to correspond to the device's address in TRAX. If you are using the manual mode in TRAX, you will need to configure SMARTPAX using its port, address and device buttons. Please refer to the SMARTPAX product sheet and the TRAX handbook for more details.

The following MIDI-related drivers are available:

- MIDI timecode drivers, for control of any MIDI timecode compatible sequencer, digital mixer, etc.

- MIDI channel drivers, for issuing note-on/note-off messages to a sampler or synthesizer for sound effects.

- Specialized drivers for lighting consoles and other non-music devices.

MIDI SMARTLINK is also capable of receiving MIDI commands from devices that can supply Note On, Note Off and level change functions.

PROGRAMMING

You program a MIDI-timecode device in the same way as you program a tape player, ie, using Locate and Trigger cues in Dataton TRAX. When a Locate cue is received, SMARTPAX transmits a short burst of MIDI timecode, forcing the device being controlled to jump to that point in time. SMARTPAX then stops the timecode at the exact start position until it receives a Play command. This command causes it to begin transmission of continuous timecode until a subsequent Stop Locate cue is received. Please note that at the time of writing, MIDI timecode support isn't yet fully implemented. Contact Dataton for the latest developments here!

MIDI channel drivers are programmed using a TRAX Locate cue, which specifies the MIDI note number, or zero, to turn the note off. You can use a Level cue

to set the velocity prior to issuing the Locate cue.

Lighting consoles and other specialized devices are also usually programmed using Locate cues. For more details, refer to the specifications for the relevant device driver in the TRAX driver database. These will also tell you how to configure the device itself in order to work with the SMARTPAX.

With TRAX 3.0 in its interactive mode, it is also possible to receive MIDI Note On, Note Off and control change inputs from this smartlink. To do this, connect your MIDI device to the female 5 pin DIN connector on the MIDI SMARTLINK. Create a Switch device and select the appropriate driver inside the device's dialog box. Specify an address and a subaddress, where the subaddress corresponds to the note number for response. The note numbers are centered around middle C; ie, subaddress 16 corresponds to this.

To start an action when a key is struck, add a task to the Task list in TRAX 3.0 and link the triggering condition field to the "Input On" status field of the switch representing the button.

Please note that these MIDI input functions are not available with versions of TRAX prior to 3.0 or with MICSOFI.

TECHNICAL SPECIFICATIONS

MIDI SMARTLINK is the physical control link between the Dataton system and a MIDI compatible device. The selected device driver downloaded in SMARTPAX handles the protocol of the device to be controlled. This includes anything from simple note-on/note-off messages, through MIDI timecode, to specialized functions such as control of MIDI compatible lighting consoles. Functions are programmed from Dataton TRAX®.

One male 5-pin DIN connector is provided for MIDI out and one female 5-pin DIN connector for MIDI in. MIDI SMARTLINK has a standard cable length of 1.6m (63"). If necessary, you can extend this with Dataton EXTENSION CABLE, article number 3451 (1m), 3452 (2m) or 3455 (5m).

MIDI SMART-LINK